



New Crazybee F4 V3.0 Frsky version bind procedure

1.Connect to Betaflight configurator then move to CLI Tab, then Type the BIND Code "bind_rx_spi"



The red LED at the bottom of the V3.0 flight controller will get to be solid, this indicates the onboard receiver is in bind mode



2.Turn on your transmitter and then move to Model setup ,select D8 mode and then ENT "bind" to binding with the onboard receiver , if bind successful the Red Led at the bottom of the flight controller will start to blink slowly . Then reconnect the USB and exit bind mode . Now move to receiver tab of the Betaflight configurator to check the receiver works

